



**PRODUCT NUMBER**  
**H1-EXT-191**

## H1 LIGHTBAR INSTRUCTION MANUAL

***Congratulations*** on the purchase of your new accessory by Predator Motorsports Inc. As with all products, proper installation is the key to obtaining all of the benefits your accessory is capable of delivering. Please take a few minutes to read through the instructions to identify the components and learn where and how they are used. It is a good idea to start by comparing the parts in your kit with the parts list below. Be sure to take all applicable safety precautions during the installation of this product.



### **Parts List**

### **Quantity**

### **Tools Required**

Light Bar	1	• 2- 9/16" Wrenches
3/8"x2.5" Bolt	2	• Phillips Head
3/8" Nylock Nut	2	
3/8" Washer	4	

### **INSTRUCTIONS**

1. Carefully remove light bar from packaging and inspect all hardware.
2. Remove top 1/4" screws from either side of center marker light mount.
3. Remove the two 3/8" bolts on the two outer hinge mounts located at the bottom of the windshield.
4. With assistance of another tech, set light bar over hood and into location aligning the bottom mounts on the outside of the window mount. Slide the supplied bolts and washers through lower mounts.
5. Attach nylock on the bolt and hand tighten.
6. Install upper stock 1/4" screws through upper mounts and center marker light bezel. Tighten.



### **Wiring Suggestions**

1. For a clean installation, wiring can be hidden on the inside of the light bar tube by drilling a hole next to each light on the inside of the rear facing tube.
2. Next route all wires through the tube to the drivers side mount and under the hood.
3. Cover the exposed wires with flex-loom.

Your Exclusive Hummer Accessory Source

Predator Technical Support Line – 760-734-1749



Copyright 2005 Predator Motorsports  
Predator Motorsports Inc. - Vista, CA USA [www.predatormotorsports.com](http://www.predatormotorsports.com)