



**PRODUCT NUMBER**  
**H1-EXT-193**

## H1 REAR LIGHTBAR INSTRUCTION MANUAL

***Congratulations*** on the purchase of your new accessory by Predator Motorsports Inc. As with all products, proper installation is the key to obtaining all of the benefits your accessory is capable of delivering. Please take a few minutes to read through the instructions to identify the components and learn where and how they are used. It is a good idea to start by comparing the parts in your kit with the parts list below. Be sure to take all applicable safety precautions during the installation of this product.



### Parts List

### Quantity

### Tools Required

Rear Light Bar Assy. with mounts	1	• Wrench Set
Rubber Pads	4	• Allen Head Set
Nylock Nuts	2	
Stainless Bolt 5/16" x 1.75" long	2	
Stainless Washer 5/16"	4	

### INSTRUCTIONS

1. Carefully remove light bar from packaging and inspect all hardware.
2. Install rubber pads onto each inside mounting surface.
3. Set light bar onto rear roll bars of the H1 with the assistance of a second person.
4. Install mounting clamps, with rubber insert on the inside of clamp, onto the light bar close over roll bar.
5. Install mounting bolt, washers and nut and tighten
6. Inspect each mount to ensure a secure installation.

### Wiring Suggestions

1. For a clean installation, wiring can be hidden on the inside of the light bar tube by drilling a hole next to each light on the inside of the outside facing tube.
2. Next route all wires through the tube to either side of the mounts and through a final hole just above the mount.
3. Route the wires inside the H1 through the soft top roll bar opening.

