



PRODUCT NUMBER
H1-INT-195

H1 REAR BUMPER INSTRUCTION MANUAL

Congratulations on the purchase of your new accessory by Predator Motorsports Inc. As with all products, proper installation is the key to obtaining all of the benefits your accessory is capable of delivering. Please take a few minutes to read through the instructions to identify the components and learn where and how they are used. It is a good idea to start by comparing the parts in your kit with the parts list below. Be sure to take all applicable safety precautions during the installation of this product.

<u>Parts List</u>	<u>Quantity</u>	<u>Tools Required</u>
Rear Bumper w/Skid Plate	1	<ul style="list-style-type: none"> • Caulking Gun
¼" Bolts with Nylock Nuts	4	<ul style="list-style-type: none"> • Soft Cloth
Bolts 3/8"	4	
Washers	8	
3/8" Nylock Nuts	4	

INSTRUCTIONS

1. Remove the 4 bolts located on the rear bumper. (2 located on each outer side of the tow hooks)
2. Remove one tow hook from the bumper to allow access to install the new bumper.
3. Remove the two bolts holding the trailer wiring harness in place.
4. Set New Rear Bumper onto stock bumper and secure with stock bolts.
5. Locate trailer wire harness to the new location and bolt in place with supplied bolts.
6. Bolt skid plate in place with supplied bolts
7. Reinstall tow hook.

