

		<u>PRODUCT NUMBER</u>
<h2>Brush Guard</h2>		
<p><i>Congratulations</i> on the purchase of your new accessory by Predator Motorsports®. As with all products, proper installation is the key to obtaining all of the benefits your accessory is capable of delivering. Please take a few minutes to read through the instructions to identify the components and learn where and how they are used. It is a good idea to start by comparing the parts in your kit with the parts list below. Be sure to take all applicable safety precautions during the installation of this product.</p>		
<u>Parts List</u>	<u>Quantity</u>	<u>Tools Required</u>
Brush Guard	1	
Spacer Tab	2	
Bolts (Long)	2	
Bolts (Short)	4	

Installation Procedure

1. Remove Front Mini Grill by pulling straight out to allow access to mounts.
2. Remove Brush Guard if equipped.
3. Set new Brush Guard into place and insert and hand tighten 4 bolts.
4. Hold spacer between inside of grill and upper bracket. Slide the long screw through upper bracket, spacer and tighten into place.
5. Check alignment of brush guard to vehicle and tighten all bolts.
6. If vehicle was not equipped with a brush guard, the side plastic pieces of the mini grill will need to be cut off. Do so by cutting along the seam line on either side of mini grill.
7. Reinstall front mini grill.

