



**PRODUCT NUMBER**  
**H2-EXT-927**

## **H2 Hood Scoop INSTRUCTION MANUAL**

***Congratulations*** on the purchase of your new accessory by Predator. As with all products, proper installation is the key to obtaining all of the benefits your accessory is capable of delivering. Please take a few minutes to read through the instructions to identify the components and learn where and how they are used. It is a good idea to start by comparing the parts in your kit with the parts list below. Be sure to take all applicable safety precautions during the installation of this product.



<b><u>Parts List</u></b>	<b><u>Quantity</u></b>	<b><u>Tools Required</u></b>	
Instructions	1	• .25" Drill Bit	• 10mm Socket
Hood Scoop	1	• Drill	•
Stainless Steel Grate	1	• Caulking Gun	•
Bonding Glue	1		

### **INSTRUCTIONS**

#### **Removal Procedure**

1. Open the hood and remove the four 10mm nuts holding the hood handles in place. (Note, it is recommended that someone assists in holding the stock hood panel and handles in place so they do not fall and cause damage.)
2. Remove the hood panel and handles from hood.

#### **Preparation**

1. Test fit new hood panel to verify fitment
2. Locate the 4 dimples, 2 on each side of the scoop and drill the 4 mounting holes with a .25" drill bit.
3. If painting cowls, prep and paint now.

#### **Installation Procedure**

1. Install Stainless Steel Grate from the back side of the scoop with the supplied bonding glue. Let it completely dry before handling.
2. Install Hood Scoop by reusing the factory hood handles and hardware. (Note, it is recommended that someone assists in holding the Hood Scoop and handles in place so they do not fall and cause damage.)