



**PRODUCT NUMBER**  
**H2-EXT-930**

## H2 Corner Light Cowl INSTRUCTION MANUAL

***Congratulations*** on the purchase of your new accessory by Predator. As with all products, proper installation is the key to obtaining all of the benefits your accessory is capable of delivering. Please take a few minutes to read through the instructions to identify the components and learn where and how they are used. It is a good idea to start by comparing the parts in your kit with the parts list below. Be sure to take all applicable safety precautions during the installation of this product.



<b>Parts List</b>	<b>Quantity</b>	<b>Tools Required</b>	
Instructions	1	•	•
Light Cowl (Left and Right)	2	•	•
Stainless Screw 4"	4	•	•
PIAA 2100 Light Set	1		

### **INSTRUCTIONS**

#### **Removal Procedure**

1. Remove corner pieces by pulling up.

#### **Preparation**

1. Test fit new cowls to verify fitment
2. Drill the two mounting holes on each cowl.
3. If painting cowls, prep and paint now.

#### **Installation Procedure**

1. Install Light Wiring Harness, routing each harness end terminal underneath each cowl. Leave approximately 6" of lead to allow for the light cowl to be installed.
2. Attach Lights to Cowl using the outer two mounting holes of light bracket and allowing for both the front and rear cowl mounting holes to be exposed.
3. Route the light wires through the cowl. Note: to reduce the size of the hole, we recommend that you cut off the end terminal from the light, run the lead through the cowl and reattach the end terminal.
4. Plug the light terminal together.
5. Align the cowl and drill an 1/8" pilot hole through the cowl and into the body from the top.
6. Install the supplied stainless screws through the light bracket on the front and rear mounts.

