



**PRODUCT NUMBER**  
H2-INT-731

## BILLET PEDAL SET INSTRUCTION MANUAL

***Congratulations*** on the purchase of your new accessory by Predator Motorsports®. As with all products, proper installation is the key to obtaining all of the benefits your accessory is capable of delivering. Please take a few minutes to read through the instructions to identify the components and learn where and how they are used. It is a good idea to start by comparing the parts in your kit with the parts list below. Be sure to take all applicable safety precautions during the installation of this product.



<u>Parts List</u>	<u>Quantity</u>	<u>Tools Required</u>
"H" Brake Pedal	1	<ul style="list-style-type: none"> <li>• Allen tool set</li> </ul>
"2" Accelerator Pedal	1	
E-Brake Pedal	1	

### INSTRUCTIONS

#### Accelerator Pedal

1. Remove ¼" allen head bolts from back side of "2" accelerator pedal. Install over accelerator pedal. Install and tighten bolts evenly.

#### Brake Pedal

1. Remove the Rubber Brake Pedal Cover.
2. Place Billet Brake Pedal Cover over the original metal brake lever pad.
3. Insert the top allen screws first and tighten, then insert the lower allen screws and tighten.

#### E-Brake Pedal

1. Remove the Rubber E-Brake Pedal Cover.
2. Place Billet E-Brake Pedal Cover over the original metal brake lever pad.
3. Insert the allen screws and tighten.

