



1250 Distribution Way, Vista CA 92081  
Phone: 760-734-1749 Fax: 760-874-2973

# H3 PREDATOR HOOD PANEL REV.7.27.06

## Warranty Information:

Your Hummer H3 Hood Panel is backed by a Lifetime Warranty on all structural parts including all spacers and brackets under normal use. Misuse and neglect is not covered under warranty. All hardware is backed by our 3 year 36,000 mile warranty. To ensure a lifetime of trouble free use, you must wash and wax the finish on the door once a month in dry climates and once a week in wet climates.

<u>Parts List</u>	<u>Quantity</u>	<u>Tools Required</u>	
10-32 X ¾" S.S. button head cap screws	3	Drill/driver	Standard Allen wrenches
10-32 X 1 ½" S.S. button head cap screws	2	3/16 drill bit	3/8" combo. wrench
#10 fender washers	3		
# 10 flat washers	2	Rev.7.26.06 parts list	
Locking nuts	5	Foam Strip	Qty. 1

- Step 1. Remove the stock hood panel by firmly lifting upward to release the clips. Clean the surface of the hood with a mild soap and water mixture and a soft cloth.
- Step 2. Open the hood and remove the seal along the front inner edge by pulling out the push-pins. Prop the hood open about 8" for access during the installation.
- Step 3. Apply adhesive foam strip to the bottom back side of the hood panel. Located between the hood panel and the hood closest to the windshield.
- Step 4. Carefully position the Predator hood panel on the hood and insert the provided 10-32 X ¾" button head cap screws. Secure loosely with fender washers and lock nuts.
- Step 5. Carefully drill through the front two holes penetrating the inner hood structure. Install remaining 10-32 X 1 ½" cap screws, flat washers and lock nuts. Tighten all hardware evenly.
- Step 6. Replace inner hood sealing strip with push-pins removed in Step 2.



**Step 1**



**Step 2**



**Step 3**



**Step 4**



**Step 5**

