



RIGHT HAND SIDE

START WITH THIS SIDE FIRST. TAPE DOWN THE TEMPLATE AND DRILL OUT HOLES WITH A 5/16" DRILL BIT. FLIP TEMPLATE OVER FOR LEFT HAND SIDE.



RIGHT HAND SIDE

START WITH THIS SIDE FIRST. TAPE DOWN THE TEMPLATE AND DRILL OUT HOLES WITH A 5/16" DRILL BIT. FLIP TEMPLATE OVER FOR LEFT HAND SIDE.



RIGHT HAND SIDE

START WITH THIS SIDE FIRST. TAPE DOWN THE TEMPLATE AND DRILL OUT HOLES WITH A 5/16" DRILL BIT. FLIP TEMPLATE OVER FOR LEFT HAND SIDE.



RIGHT HAND SIDE

START WITH THIS SIDE FIRST. TAPE DOWN THE TEMPLATE AND DRILL OUT HOLES WITH A 5/16" DRILL BIT. FLIP TEMPLATE OVER FOR LEFT HAND SIDE.

LEFT HAND SIDE

LEFT HAND SIDE

LEFT HAND SIDE

LEFT HAND SIDE