



PRODUCT NUMBER
H3-EXT-651

BILLET HOOD HANDLE INSTRUCTION MANUAL

Congratulations on the purchase of your new accessory by Predator Motorsports Inc. As with all products, proper installation is the key to obtaining all of the benefits your accessory is capable of delivering. Please take a few minutes to read through the instructions to identify the components and learn where and how they are used. It is a good idea to start by comparing the parts in your kit with the parts list below. Be sure to take all applicable safety precautions during the installation of this product.



Parts List

Quantity

Tools Required

Billet Hood Handle
 M6x1 14MM Long
 1/4" Fender Washers

2
 4
 4

- Rubber Mallet
- Drill
- Prying Tool
- 5mm Allen Wrench
- 5/16" Drill Bit
- Non-Scratch Tape

INSTRUCTIONS

1. Open the hood and gently tap the top three tabs loose with a rubber mallet.
2. Close the hood and gently pry the hood insert loose with a tool that will not scratch the painted hood surface. (You may want to wrap the pry tool with a non-scratch tape.)
3. Starting with the right side first, install the billet hood handles using the provided template for holes. Attach the hood handles using the supplied fasteners.
4. Reuse the template by flipping over for the left hand side and continue with step 3 for the left hand hood handle.
5. Re-install the hood insert confirming that all 10 tabs are securely in place as originally installed.

