



**PRODUCT NUMBER**  
**H3-EXT-682**

## **INSTALLATION INSTRUCTIONS FOR PREDATOR H3 CORNER LIGHT COWL SET**

***Congratulations*** on the purchase of your new accessory by Predator Motorsports. As with all products, proper installation is the key to obtaining all of the benefits your accessory is capable of delivering. Please take a few minutes to read through the instructions to identify the components and learn where and how they are used. It is a good idea to start by comparing the parts in your kit with the parts list below. Be sure to take all applicable safety precautions during the installation of this product.



<b>Parts List</b>	<b>Quantity</b>	<b>Tools Required</b>
Light Cowl Right Hand Side	1	
Light Cowl Left Hand Side	1	
Light Set w/wiring	1	
¼-20 bolts	4	
¼" washers	8	
¼-20 Nylock Nuts	4	

### **INSTRUCTIONS**

1. Set Light Assembly into Light Cowl. Locate the slots on the light mount and mark two outer drill locations on light cowl. Drill two holes using a ¼" drill bit.
2. Mount Light Assembly to Light Cowl using the supplied bolts, washers and nuts.
3. Drill a third ¼" hole just behind the light wire leads and route wires through the cowl.
4. Repeat steps 1-3 for opposite side Light Cowl.
5. Remove the factory Cowls by firmly pulling directly up on to "unsnap" the cowl.
6. Remove all "snap clips" from the factory part and relocate onto the light cowl.
7. Install wire harness and route leads to each light cowl area.
8. Connect the wire harness leads to the light assembly and snap the Light Cowl to the vehicle.

