



PRODUCT NUMBER

H1-EXT-156

H1-EXT-157

H1-EXT-158

H1 SNORKEL INSTRUCTION MANUAL

Congratulations on the purchase of your new accessory by Predator Motorsports®. As with all products, proper installation is the key to obtaining all of the benefits your accessory is capable of delivering. Please take a few minutes to read through the instructions to identify the components and learn where and how they are used. It is a good idea to start by comparing the parts in your kit with the parts list below. Be sure to take all applicable safety precautions during the installation of this product.



Off-Set Snorkel



Tall Snorkel



Short Snorkel

Parts List

Quantity

Tools Required

Snorkel w/Precleaner
1/4" Sheet Metal Screws

1
4

- Flat Head
- 7/16" Wrench

- Phillips Head
-

INSTRUCTIONS

1. Remove the factory snorkel assembly.
2. Set the snorkel tube on the truck. Align the holes on the base of snorkel to the body holes. Insert and loosely tighten the screws.
3. Set precleaner on the snorkel tube. Align snorkel to the position you desire. (predator recommends the side dust opening be 90 degrees to the side of the vehicle)
4. Lift the precleaner up slightly to expose the slots. With a black pen mark the 4 slot locations on the tube 3/8" down from the top of the tube.
5. Remove the precleaner from the snorkel and remove the snorkel from the H1.
6. Drill the hole location with a 1/4" drill bit. Remove all aluminum drill chips from the inside of the tube.
7. Slide precleaner down over snorkel tube. Insert and tighten the 4 supplied screws.
8. Install Snorkel on vehicle and tighten in place.

