

Predator Motorsports

1250 Distribution Way Vista CA 92081

Phone: 760-734-1749 Fax: 760-874-2973

www.predatormotorsports.com

e-mail: Sales@predatormotorsports.com

H2 Stainless Dash Bolt Kit

Kit Includes:

1. 1- 5mm Hex Wrench
2. 10- Stainless Steel Dome Machine Bolts

Installation:

1. Remove the 10 zinc plated factory bolts from dash using the 5mm Hex Wrench. Note: It is common for the factory bolts to bind while being removed.
2. Install the 10 Stainless Steel Dome Machine Bolts into dash. For each panel, leave the bolts about ½ turn out. Align dash panel to screws for a centered finish fit and tighten.

If you have any technical questions or comments please call our technical support line at 760-734-1749.

We thank you for your recent purchase and look forward to helping you in any way possible.

Predator Motorsports

1250 Distribution Way Vista CA 92081

Phone: 760-734-1749 Fax: 760-874-2973

www.predatormotorsports.com

e-mail: Sales@predatormotorsports.com

H2 Stainless Dash Bolt Kit

Kit Includes:

1. 5mm Hex Wrench
2. 10- Stainless Steel Dome Machine Bolts

Installation:

1. Remove the 10 zinc plated factory bolts from dash using the 5mm Hex Wrench. Note: It is common for the factory bolts to bind while being removed.
2. Install the 10 Stainless Steel Dome Machine Bolts into dash. For each panel, leave the bolts about ½ turn out. Align dash panel to screws for a centered finish fit and tighten.

If you have any technical questions or comments please call our technical support line at 760-734-1749.

We thank you for your recent purchase and look forward to helping you in any way possible.