



PRODUCT NUMBER
H2-EXT-628

BILLET TAIL VENT INSTRUCTION MANUAL

Congratulations on the purchase of your new accessory by Predator Motorsports®. As with all products, proper installation is the key to obtaining all of the benefits your accessory is capable of delivering. Please take a few minutes to read through the instructions to identify the components and learn where and how they are used. It is a good idea to start by comparing the parts in your kit with the parts list below. Be sure to take all applicable safety precautions during the installation of this product.



| <u>Parts List</u> | <u>Quantity</u> | <u>Tools Required</u> |
|----------------------|-----------------|--|
| Left Hand Tail Vent | 1 | <ul style="list-style-type: none"> • T-30 Torx Driver |
| Right Hand Tail Vent | 1 | |
| | 1 | |

INSTRUCTIONS

Removal Procedure

1. Open the lift gate.
2. Remove the two side retaining screws.
3. Pull rearward on the tail vent to disengage the clips from the body.

Installation Procedure

1. Place the tail vent in the opening.
2. Install the two side retaining screws.
Tighten fasteners to 26 in/lbs.
3. Carefully close the lift gate watching for clearance.

